



## Specialty Products **FAQ**

82090

### GM Rear Camber/Toe Cam

**Q1: I am aligning a GM car using part number 82090 rear camber/toe bolts. How many bolts will I need?**

**A1:** Since adjusting camber will affect toe settings on this style of rear suspension, you will need to use 2 cam bolts per wheel if camber change is desired. One (1) cam bolt for the camber adjustment and one (1) cam bolt for the toe adjustment. The cam bolts are packaged 1 per box so you may need to purchase up to 4 kits per car.

