

PART NO. 77880

Instruction Sheet

COMBINATION SLEEVE PULLER

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

This sleeve puller is designed for use with Ford original equipment and most after-market camber/caster truck sleeves. Before using this puller, break the taper between the upper ball joint and the alignment sleeve. Make sure the puller is fully seated under the alignment sleeve and the puller stud is properly aligned with the ball joint stud before attempting to remove the sleeve.

CAUTION: To eliminate ball joint stud damage, turn the ball joint nut upside down and thread onto the stud until the nut is flush with the top of the stud before pulling the sleeve.
Not for use with impact wrenches. Always wear safety glasses when using this tool.



**Specialty
Products
Company**[®]

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103

www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Toll Free Technical Hot Line: 1-800-525-6505

©2004 Specialty Products Co. • Printed in U.S.A. • Form No. 99880 • Rev. 9/04