

# PART NO. 87520

## Instruction Sheet CAM KIT

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

**Plan Ahead - Read All Instructions BEFORE installing part.**

Check for loose or worn parts, proper tire pressure, and odd tire wear patterns before beginning alignment.

1. Take alignment readings and determine the amount of camber/caster change needed.
2. Raise vehicle by frame and remove the lower "A" arm mounting bolts.  
**CAUTION: Always use appropriate safety devices to support the weight of the vehicle while servicing any suspension component.**
3. Install cam bolts by placing one cam on the head of each bolt.
4. Install the bolts through the "A" arm, install the cam washers, install the nuts and tighten slightly.
5. Adjust cam bolts to desired camber/caster settings and torque nuts to manufacturer's specifications while holding the head of the bolt.
6. Adjust toe and road test vehicle.

***Always check for proper clearance between suspension components and other components of the vehicle.***



**Specialty  
Products  
Company®**

4045 Specialty Pl • Longmont, CO 80504 • (303) 772-2103

**For warranty information go to: [www.specprod.com/warranties](http://www.specprod.com/warranties)**

[www.specprod.com](http://www.specprod.com) • Email: [info@specprod.com](mailto:info@specprod.com) Printed in U.S.A.

**Toll Free Technical Hot Line: 1-800-525-6505**

ECN#3605

©2024 Niwot Corp. dba Specialty Products Co. • Form No. 87520INS • Rev. A