



Part number 87280

Caster Cam Kit

Q1: Are special tools required for the installation of the 87280 Caster Cam kit?

A1: A piloted hole saw is required for the first installation of the cam kit. This is necessary to enlarge the hole the cam will reside in. The pilot is necessary to stabilize the hole saw.

Q2: Does SPC offer the required tools?

A2: The 85770 and 85780 kits are no longer available.

Q3: Can the required tools be obtained elsewhere?

A3: The tool needed can be fabricated. Start with a common 1-1/4" metal cutting hole saw which uses a 1/4" diameter pilot. Use a steel shaft collar with a 1/4" ID and a 3/4" OD to pilot the hole saw in the vehicle. (Steel is suggested as a more durable alternative to nylon.) Shaft collars can be obtained through various hardware suppliers such as McMaster-Carr or Fastenal. Some local hardware stores may even have collars in-stock or may be able to order one. Any subsequent installations or further adjusting of the caster cam kit in this specific location on this vehicle will not require additional use of the hole saw.

