



## **Specialty Products** **FAQ**

Part Numbers 94304/94306

### **Muscle Car Arm Ball Joint Spacer Kits**

**Q1: I need to use Ball Joint Spacers on my Muscle Car Upper Control Arms, what is the maximum number of spacers I can use?**

**A1:** You should only use 3 spacers. If more height is needed use a ½ inch extended ball joint and no more than three spacers. Using more than 3 spacers may put too much stress on the ball joint plate, causing it to fail.

