

**JEEP
REPLACEMENT
REAR ARMS**

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part.

Check for loose or worn parts, proper tire pressure, and odd tire wear patterns before beginning alignment.

1. Remove rear lower control arm by removing frame bolt and axle bolt.

NOTE: Replace only 1 arm at a time for safety and ease of installation.

2. Install SPC arm with xAxis™ joint located at frame and rubber bushing joint at axle.
3. Reinstall control arm bolts and torque to factory specification with vehicle at ride height.

NOTE: Tightening fasteners with vehicle in raised position may cause premature bushing failure.

4. Repeat steps for opposite side.
5. Complete alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company®**

4045 Specialty Pl • Longmont, CO 80504 • (303) 772-2103

For warranty information go to: www.specprod.com/warranties

www.specprod.com • Email: info@specprod.com Printed in U.S.A.

Toll Free Technical Hot Line: 1-800-525-6505

ECN#2858

©2021 Niwot Corp. dba Specialty Products Co. • Form No. 13426INS • Rev. 3/21